




ND_PANDA_1511A
open_hardware



SCL

SDA



KEY1

GND

DC

DD

NRESET

GND

3V3

GND

LED1

LED2

LED3

CLK

CS

TXD

RXD

3V3